


# User's Guide

## MC-MNR 5G Router



## TABLE OF CONTENTS

|  |           |
|--|-----------|
| <b>1 Introduction</b> .....                    | <b>4</b>  |
| 1.1 Purpose of the manual .....                | 4         |
| 1.2 Target audience .....                      | 4         |
| 1.3 Overview of the device .....               | 4         |
| <b>2 Variants</b> .....                        | <b>5</b>  |
| 2.1 Basic features .....                       | 5         |
| 2.2 Product matrix .....                       | 5         |
| <b>3 Warranty provisions</b> .....             | <b>6</b>  |
| 3.1 Limitation of liability .....              | 6         |
| 3.2 Approved accessories .....                 | 6         |
| 3.3 Inspection for damages .....               | 6         |
| 3.4 Technical limits .....                     | 6         |
| <b>4 Safety instructions</b> .....             | <b>7</b>  |
| 4.1 Obligations of the operator .....          | 7         |
| 4.2 Qualification of installers .....          | 7         |
| 4.3 Guidelines for transport and storage ..... | 7         |
| <b>5 Electric safety</b> .....                 | <b>8</b>  |
| 5.1 Electric safety requirements .....         | 8         |
| 5.2 Electric safety precautions .....          | 8         |
| <b>6 Product care and handling</b> .....       | <b>9</b>  |
| 6.1 Maintenance .....                          | 9         |
| 6.2 Troubleshooting .....                      | 9         |
| 6.3 Repair .....                               | 9         |
| <b>7 Environmental protection</b> .....        | <b>10</b> |
| 7.1 Disposal .....                             | 10        |
| <b>8 Technical limits</b> .....                | <b>11</b> |
| <b>9 Hardware</b> .....                        | <b>12</b> |
| 9.1 Block diagram .....                        | 12        |
| 9.2 Insertion of SIM cards .....               | 13        |
| 9.3 Configuration of Radio interfaces .....    | 13        |
| 9.4 LEDs .....                                 | 16        |
| 9.5 Connector overview on MC-MNR front .....   | 18        |
| 9.5.1 Power Connector .....                    | 19        |

## MC-MNR 5G Router

|  |           |
|--|-----------|
| 9.5.2 Ethernet Connectors                      | 20        |
| 9.5.2.1 RJ45                                   | 20        |
| 9.5.2.2 M12 X-coded connector for RJ45 mapping | 21        |
| 9.5.3 IO Connector                             | 21        |
| 9.5.4 M8 Audio Connector                       | 22        |
| 9.5.5 USB-A connector                          | 22        |
| 9.6 Connector overview on MC-MNR back          | 23        |
| 9.7 Buttons                                    | 23        |
| 9.8 GNSS                                       | 24        |
| <b>10 Watchdog System in MNR</b>               | <b>26</b> |
| 10.1 User-Space Inaccessibility                | 26        |
| 10.2 Kernel Crash                              | 26        |
| 10.3 ADV-I2C-WDT                               | 26        |
| 10.3.1 Usage via UBUS                          | 26        |
| 10.3.2 Usage Without Watchdog Daemon           | 27        |
| 10.4 STM32-WDT                                 | 27        |
| <b>11 Initial Startup of router</b>            | <b>28</b> |
| <b>12 Contact information</b>                  | <b>31</b> |

## 1 INTRODUCTION

Thank you for choosing an MC Technologies product.

### 1.1 PURPOSE OF THE MANUAL

This document provides comprehensive instructions for the installation, operation, and maintenance of the 5G Router MC-MNR. It aims to ensure that users can effectively utilize the device while adhering to all relevant safety and regulatory standards.

### 1.2 TARGET AUDIENCE

This manual is intended for users who will be installing and operating the 5G Router MC-MNR in various environments, including vehicles, offices, machinery, and control cabinets. It assumes that the reader has basic technical knowledge and skills, but no special training or qualifications are required to follow the instructions provided.

### 1.3 OVERVIEW OF THE DEVICE

The 5G Router MC-MNR is a high-performance, Linux-based router designed for M2M (Machine-to-Machine) and industrial IoT (Internet of Things) applications. It integrates several advanced technologies to provide robust connectivity and reliable performance in various industrial and commercial environments. Key features include:

- **5G Technology:** Provides high-speed, low-latency connectivity for demanding applications.
- **LTE Support:** Ensures reliable connectivity in areas where 5G coverage is not available.
- **Wifi 2.4 GHz:** Offers wireless networking capabilities for local area connections.
- **GNSS Receiver:** Provides precise location tracking and navigation capabilities.

The MC-MNR is equipped with an industrial-grade RK3568 quad-core ARM Cortex-A55 processor, delivering outstanding performance per watt for embedded industrial IoT gateway and edge computing solutions. Its integrated GPU and 1 TOPs@INT8 NPU make it future-proof for advanced multimedia processing and machine learning frameworks, essential for applications such as robotics control, real-time diagnostics, surveillance, and image recognition.

## 2 VARIANTS

As an OEM, MC Technologies may produce variants of the MC-MNR deviating from the variants listed herein. For the basic variants model-specific information may be found in dedicated appendices on our website:

[mc-technologies.com/service-support/download](https://mc-technologies.com/service-support/download)

In case, your model is not listed there, please contact your supplier for the correct user's guide.

### 2.1 BASIC FEATURES

All MC-MNR basic variants possess the following features:

- 2 x M.2 mPCIe extension slots (can be equipped to e.g. operate two 4G/5G network cards in parallel for increased availability)
- 2.4 GHz WiFi
- Externally accessible USB 3.0 port
- High precision GNSS
- 4 x Digital Input, 4x Digital Output
- 2 x Current-sense ADC (4...20 mA)
- 2 x Voltage-sense ADC (0...30 V)

### 2.2 PRODUCT MATRIX

This product matrix outlines the basic variants of models:

| Interface     | MNR-5GA<br>194110 | MNR-5G<br>194174 | MNR-450<br>194175 | MNR-DLTE<br>194176 | MNR-LTE<br>194177 |
|---------------|-------------------|------------------|-------------------|--------------------|-------------------|
| M.2 Slot      | 5G                | 5G               | -                 | 4G                 | 4G                |
| mPCIe Slot    | 4G                | -                | 450 MHz           | 4G                 | -                 |
| Ethernet RJ45 | 2x                | 2x/4x            | 2x/4x             | 2x/4x              | 2x/4x             |
| Ethernet M12  | 2x                | -                | -                 | -                  | -                 |
| Audio         | ✓                 | -                | -                 | -                  | -                 |
| Datasheet     | MNR-5GA           | MNR-5G           | MNR-450           | MNR-DLTE           | MNR-LTE           |

## 3 WARRANTY PROVISIONS

Unauthorized use, non-observance of this documentation, the operation or maintenance by insufficiently qualified persons, and unauthorized modifications exclude the manufacturer's liability for resulting damages. Any modification to the device will void the manufacturer warranty. The provisions of our General Terms of Sale (AGB) apply. These can be found on our website:

<https://mc-technologies.com/en/agb-aeb>

### 3.1 LIMITATION OF LIABILITY

The manufacturer and seller are not liable for damages caused by improper use, installation or maintenance. This includes consequential damage, personal injury, damage to property and damage caused by failure to observe the safety instructions. This exclusion of liability does not affect the statutory warranty claims. Liability is assumed for material and manufacturing defects within the statutory warranty period.

### 3.2 APPROVED ACCESSORIES

This device must only be operated with suitable accessories approved for the appliance.

### 3.3 INSPECTION FOR DAMAGES

Check the device and all components for damages or anomalies before use. Do not use the appliance if it is damaged or shows signs of wear. Make sure that all cables are in a good condition. The appliance must not be used if cables or plugs are damaged.

### 3.4 TECHNICAL LIMITS

The product is exclusively intended for use within the technical limitations and maximum ratings specified in this document. The following limitations must be observed in particular:

- The ambient temperature must not be exceeded or dropped below limits.
- The maximum air humidity must not be exceeded, and condensation must be avoided.
- The supply voltage must be within limits and maximum input ratings must not be exceeded.
- The maximum switching voltage and current must not be exceeded.

## 4 SAFETY INSTRUCTIONS

These instructions enable the safe and efficient handling of the product. The instructions are an integral part of the product and must always be kept accessible to installation, maintenance, commissioning, and operating persons.

The safety and maintenance instructions must be strictly followed to ensure safe operation of the product. Only the consideration of all safety guidelines ensures protection of persons and the environment against hazards and the safe and trouble-free operation of the product.

General safety regulations and local guidelines for the area of application of the device as well as for the prevention of accidents along with procedures and operation instructions with safety-critical information must be followed strictly.

### 4.1 OBLIGATIONS OF THE OPERATOR

The operator must follow regional regulations regarding the operation, functional testing, repair and maintenance of electronic devices at all times.

### 4.2 QUALIFICATION OF INSTALLERS

Installation and maintenance of the product may only be carried out by trained authorised installers which possess the necessary levels of qualification to ensure safe maintenance and operation. The qualified installer must have read and understood this documentation and follow its guidelines and instructions. This product may only be operated by or under the supervision of trained persons.

### 4.3 GUIDELINES FOR TRANSPORT AND STORAGE

- Do not expose the product to moisture or other potentially harmful environmental conditions (radiation, gases, etc.) during transport or storage
- Protect the product from shocks during transport and storage (e.g. by using air-cushioned packaging)
- Before installing the product, check for damages caused by improper transport or storage. Damage in transit must be noted on the shipping documents. All claims for damages must be made immediately and before being handed to the carrier or company responsible for the storage or logistics respectively.

## 5 ELECTRIC SAFETY

### 5.1 ELECTRIC SAFETY REQUIREMENTS

Electrical installation, maintenance and commissioning of products operated with high or low voltage ( $\geq 50$  V AC or  $\geq 120$  V DC respectively) may only be carried out by persons who, due to their specialist training, knowledge and experience including knowledge of the relevant standards and regulations, are authorized to carry out work on electrical systems and independently detect and avoid possible hazards e.g. as described in VDE 1000-10.

The electrical installation must be conducted in line with all applicable standards and regulations such as VDE 0100-200 and VDE 0105-100 while considering necessary safety requirements such as DIN VDE 0100-410. The electrical installation must only be operated when defect-free and after testing using a recognized examination procedure like VDE 0100-600 / IEC 60364-6, with all necessary safety measures in place before operation.

Equipment must be inspected immediately after installation, expansion or any other change e.g. according to DIN EN 50699 (VDE 0702). The inspector must be qualified for inspection as e.g. described in TRBS 1203 to perform inspections and determine the inspection intervals through a risk assessment process. The resulting inspection report must be archived. Equipment passing the inspection should be marked by an inspection sticker summarizing the results and showing the next due date.

### 5.2 ELECTRIC SAFETY PRECAUTIONS

- The appliance needs to be switched off before connecting it to the mains
- Improper installation can lead to electric shocks, short circuits or fires
- The cabling must be suitable e.g. according to DIN VDE 0100-520
- The supplying electric installation must be equipped with a residual-current device (RCD)



## 6 PRODUCT CARE AND HANDLING

### 6.1 MAINTENANCE

The product is maintenance-free and requires no special regular maintenance. The device may however require regular inspection (see chapter *Electric safety requirements*).

### 6.2 TROUBLESHOOTING

If a fault occurs during operation of the product and you need assistance, please contact MC Technologies support. You can reach our support department by email or phone:  
support@mc-technologies.com +49-511-676 999-126

### 6.3 REPAIR

Only qualified personnel at MC Technologies GmbH are authorised to perform repairs. Send defective products with a detailed error description to:

MC Technologies  
-Repair-  
Kabelkamp 2  
30179 Hannover  
Germany

Before shipping the device make sure to:

- call our support team and ask for an RMA number (Return to Manufacturer Authorisation)
- remove any personal belongings like inserted SIM cards
- back up any relevant data like configurations on the device

## 7 ENVIRONMENTAL PROTECTION

The product and the associated transport packaging are made largely from recyclable raw materials. It can be sent to MC Technologies GmbH for proper recycling. At the end of its useful life, the product must not be disposed as household waste.

The disposal of the product and its packaging must be carried out in accordance with all relevant environmental protection regulations. Recycle responsibly by separating the packaging materials like cardboard and paper from plastic and use the dedicated waste collection systems.

### 7.1 DISPOSAL

In accordance with WEEE regulations, we offer the return and recycling of old MC Technologies equipment. For disposal, please send it carriage paid to the following address:

MC Technologies  
-Disposal-  
Kabelkamp 2  
30179 Hannover  
Germany

## 8 TECHNICAL LIMITS


| Physical characteristic / limitation | Value  |
|--------------------------------------|--|
| Type                                 | 5G Router  |
| Dimensions (W x H x D)               | 44 x 105 x 124 mm                                |
| Weight                               | approx. 500 g                                    |
| Supply voltage                       | 8...30 V DC                                      |
| Operating temperature                | -40°C...+70°C                                    |
| Storage temperature                  | -40°C...+85°C                                    |
| Housing                              | Aluminium  |
| Protection class                     | IP20   |
| Mounting                             | DIN rail, wall mounted                           |
| Processor                            | ARMv8, 64 bit, Cortex A55, Quad Core, up to 2GHz |
| RAM                                  | LPDDR4 2 GByte                                   |
| eMMC                                 | 16 GByte   |
| Operating System                     | OpenWrt 24 [^1]                                  |

[^1]: open-source programmable and configurable embedded Linux system

## 9 HARDWARE

### 9.1 BLOCK DIAGRAM

The following diagram shows a schematic overview of the components available in the MC-MNR product line.



## 9.2 INSERTION OF SIM CARDS

The MNR can be equipped with 2x nano SIM (eSIM optional).

**Preparation:** Ensure the router is powered off. Locate the dual SIM card tray on the device.


**Insertion:** SIM1 (5G Module): Insert the nano SIM card designated for the 5G module (M2) into the SIM1 slot with the metal contacts facing downward. SIM2 (LTE Module): Insert the nano SIM card designated for the LTE module (mPCIe) into the SIM2 slot with the metal contacts facing upward. Tray Installation: Carefully slide the dual SIM card tray back into the device until it clicks securely into place.

**Power On:** Turn on the router and verify that both SIM cards are detected and functioning correctly.




## 9.3 CONFIGURATION OF RADIO INTERFACES


The radio modules are configured via the webinterface. The Modem status page shows the state of each radio module, SIM card and its internet connection:



Before the radio modules can establish an internet connection APN and SIM-Pin for each module and SIM-card needs to be configured. Please navigate to the network interfaces page and edit SIM-Pin and APN. The interface named with "m1" stands for the 5G-Module, The interface named with "m2" stands for the LTE-Module



The following picture shows the edit window to edit SIM-Pin and APN for the 5G-Module:



Here is a collection of APNs for German providers.









| Provider        | APN                   |
|-----------------|-----------------------|
| Telekom         | internet.telekom      |
| Vodafone        | web.vodafone.de       |
| O2 (Telefónica) | internet              |
| 1&1             | internet              |
| Congstar        | internet.telekom      |
| Aldi Talk       | internet.eplus.de     |
| Blau            | internet.eplus.de     |
| Fonic           | pinternet.interkom.de |
| Drillisch       | internet              |
| Tchibo Mobil    | web.vodafone.de       |
| simyo           | internet.eplus.de     |
| Yourfone        | internet.eplus.de     |
| sim.de          | internet              |
| wherever SIM    | wsim                  |

### 9.4 LEDES

The MC-MNR contains 8 LEDs on the front side plus two status LEDs for each Ethernet interface.


The 8 LEDs are assigned as follows:

**LEDs**

|   |  |
|---|--|
| PWR  | 5G    |
| POS  | 4G    |
| VPN  | 2G    |
| GP1  | WiFi  |




| LED # | Name | Color | Function              | State: on                               | State: off   | State: blinking          | State: flash 3s pause |
|-------|------|-------|-----------------------|---|--------------|--------------------------|-----------------------|
| 1     | 5G   | Green | 5G network activity   | 5G Link Up                              | 5G Link Down | 5G Data traffic          | establish connection  |
| 2     | 4G   | Green | 4G network activity   | 4G Link Up                              | 4G Link Down | 4G Data traffic          | establish connection  |
| 3     | 2G   | Green | 2G network activity   | 2G Link Up                              | 2G Link Down | 2G Audio call            | establish connection  |
| 4     | WIFI | Green | WLAN network activity | Access Point active or Client connected | Power off    |                          |                       |
| 5     | PWR  | Green | Power indicator       | Power on                                | Power off    |                          |                       |
| 6     | POS  | Green | GNSS                  | GNSS fix                                | Power off    | OpenWrt boot in progress | establish connection  |
| 7     | VPN  | Green | VPN network status    | Connected                               | Turned OFF   | data transfer            | establish connection  |
| 8     | GP1  | Red   | Error indicator       | ERROR                                   | Status Okay  | SW Update                |                       |



| Port #       | Green LED | Orange LED | Function                        |
|--------------|-----------|------------|---------------------------------|
| LAN 1 , 2, 3 | off       | off        | Link Down / no cable inserted   |
| LAN 1 , 2, 3 | on        | on         | 10 MBit Link up                 |
| LAN 1 , 2, 3 | blinking  | blinking   | 10 MBit Link up & data Traffic  |
| LAN 1 , 2, 3 | on        | off        | 100 MBit Link up                |
| LAN 1 , 2, 3 | blinking  | off        | 100 MBit Link up & data Traffic |
| LAN 1 , 2, 3 | off       | on         | 1 Gbit Link up                  |
| LAN 1 , 2, 3 | off       | blinking   | 1 GBit Link up & data Traffic   |

| Port # | Left, Green LED | Right Dual Color LED | Function                        |
|--------|-----------------|----------------------|---------------------------------|
| LAN 4  | off             | off                  | Link Down / no cable inserted   |
| LAN 4  | off             | green on             | 10 MBit Link up                 |
| LAN 4  | off             | green blinking       | 10 MBit Link up & data Traffic  |
| LAN 4  | on              | off                  | 100 MBit Link up                |
| LAN 4  | blinking        | off                  | 100 MBit Link up & data Traffic |
| LAN 4  | off             | orange on            | 1 Gbit Link up                  |
| LAN 4  | off             | orange blinking      | 1 GBit Link up & data Traffic   |

## 9.5 CONNECTOR OVERVIEW ON MC-MNR FRONT



| Name  | Connector Type | Function  |
|-------|----------------|---|
| POW   | Power          | Plug-in screw-type terminal                                     |
| ETH   | Ethernet       | 2x RJ45 + 2x M12 X-coded 10/100/1000 Base-T(X) acc. IEEE 802.3  |
| AIN   | Analog Inputs  | 2x 0 - 30 V + 2x 4 - 20 mA                                      |
| RS485 | RS-485         | on IO-connector   |
| USB   | USB-A          | USB 3.0   |
| DOUT  | Digital Output | 4x 0 - 30 V (open drain)  |
| DIN   | Digital Input  | 4x 0..30 V [ <sup>1</sup> ]                                     |
| Audio | Audio          | M8 microphone input and speaker output for calls via LTE module |

[<sup>1</sup>]: optional ignition power logic for vehicle use

### 9.5.1 POWER CONNECTOR

The router must be operated using a LPS (limited power source) power supply (according to IEC82368-1) with a supply voltage of 8 - 30V DC and a minimum rated output power of 18 W.

Warning: Make sure the polarity is correct as it might otherwise destroy the device.

| Pin | Label | Function |
|-----|-------|----------|
| -   | -     | GND      |
| +   | +     | 8V-30V   |

## 9.5.2 ETHERNET CONNECTORS

### 9.5.2.1 RJ45

#### T568A Standard (10/100 Mbps)

| Pin   | cable color  | function                     |
|-------|--------------|------------------------------|
| Pin 1 | White/Green  | TX+ (Transmit Data Positive) |
| Pin 2 | Green        | TX- (Transmit Data Negative) |
| Pin 3 | White/Orange | RX+ (Receive Data Positive)  |
| Pin 4 | Blue         | Not used (10/100 Mbps)       |
| Pin 5 | White/Blue   | Not used (10/100 Mbps)       |
| Pin 6 | Orange       | RX- (Receive Data Negative)  |
| Pin 7 | White/Brown  | Not used (10/100 Mbps)       |
| Pin 8 | Brown        | Not used (10/100 Mbps)       |

#### 1000Base-T (Gigabit Ethernet)


| Pin   | cable color  | function                               |
|-------|--------------|--|
| Pin 1 | White/Orange | BI_DA+ (Bidirectional Data A Positive) |
| Pin 2 | Orange       | BI_DA- (Bidirectional Data A Negative) |
| Pin 3 | White/Green  | BI_DB+ (Bidirectional Data B Positive) |
| Pin 4 | Blue         | BI_DC+ (Bidirectional Data C Positive) |
| Pin 5 | White/Blue   | BI_DC- (Bidirectional Data C Negative) |
| Pin 6 | Green        | BI_DB- (Bidirectional Data B Negative) |
| Pin 7 | White/Brown  | BI_DD+ (Bidirectional Data D Positive) |
| Pin 8 | Brown        | BI_DD- (Bidirectional Data D Negative) |

#### 9.5.2.2 M12 X-CODED CONNECTOR TOR RJ45 MAPPING

This table shows the pin mapping between an M12 X-coded connector and an RJ45 cable. This configuration ensures correct and efficient data transmission between the two connector types.

| M12 X-coded Pin | RJ45 Pin | Description                            |
|-----------------|----------|--|
| Pin 1           | Pin 1    | TX+ (Transmit Data Positive)           |
| Pin 2           | Pin 2    | TX- (Transmit Data Negative)           |
| Pin 3           | Pin 3    | RX+ (Receive Data Positive)            |
| Pin 4           | Pin 6    | RX- (Receive Data Negative)            |
| Pin 5           | Pin 4    | BI_DC+ (Bidirectional Data C Positive) |
| Pin 6           | Pin 5    | BI_DC- (Bidirectional Data C Negative) |
| Pin 7           | Pin 7    | BI_DD+ (Bidirectional Data D Positive) |
| Pin 8           | Pin 8    | BI_DD- (Bidirectional Data D Negative) |

#### 9.5.3 IO CONNECTOR



| Pin        | Label                 | Function  |
|------------|-----------------------|---|
| DOx A      | Digital Output port A | Isolated Open Drain Output between Port A and B |
| DOx B      | Digital Output port B | Isolated Open Drain Output between Port A and B |
| RS485 N, P | RS-485 interface      | serial interface using RS485                    |
| DIx        | Digital Inputs        | Digital Input (0-30V) with reference to GND     |
| I-INx +/-  | Analog Current Input  | Analog 4-20mA Current Input                     |
| V-INx +/-  | Analog Voltage Input  | Analog 0 - 30V Voltage Input                    |


#### 9.5.4 M8 AUDIO CONNECTOR

| Pin   | Label         | Function     |
|-------|---------------|--------------|
| Pin 1 | GND           | GND          |
| Pin 2 | Speaker out   | Audio Output |
| Pin 3 | not connected | NA           |
| Pin 4 | Microphone in | Audio Input  |

#### 9.5.5 USB-A CONNECTOR

| Pin   | Label | Function      |
|-------|-------|---------------|
| Pin 1 | VCC   | +5V (Power)   |
| Pin 2 | D-    | Data Negative |
| Pin 3 | D+    | Data Positive |
| Pin 4 | GND   | Ground        |

### 9.6 CONNECTOR OVERVIEW ON MC-MNR BACK




| Name     | Connector Type                        | Function                            |
|----------|---------------------------------------|-------------------------------------|
| M1-M4    | SMA-antenna connector female          | 5G MiMo antenna                     |
| T1+T2    | SMA-antenna connector female          | 2G / LTE antenna with diversity     |
| GNSS     | SMA-antenna connector female          | active GNSS antenna                 |
| WIFI     | SMA-antenna connector female          | 2.4 GHz WIFI antenna                |
| Nano SIM | slot for SIM card tray                | inserting tray with SIM A and SIM B |
| Micro SD | push pull connector for Micro SD card | insertion of Micro SD card          |

### 9.7 BUTTONS

## MC-MNR 5G Router

The MC-MNR has two buttons behind the back plate, a "RST" button and a "PWR" button. Those buttons can be used using a paper clip.



The "RST" button issues a factory reset. Press and hold Reset Button while powering on the device

**Attention:** A factory reset deletes all stored data and configuration of the system"

Additionally there are two other way to initiate a factory reset: - Shell: firstboot -y - LuCI: System → Backup/Flash Firmware → Perform Reset

The "PWR" button issues a restart of the Linux system. It can be pressed and released at any time.

**Attention:** Do not press this button whilst an software update!

## 9.8 GNSS

The MC-MNR is equipped with an industrial high-precision Multi-GNSS supporting concurrent reception of GPS, GLONASS, BDS, Galileo and QZSS, promising fast and accurate fixes even under rough conditions in interference-plagued environments.

- Low power consumption
- Industry-leading sensitivity
- Integrated LNA for improved sensitivity
- Embedded multi-tone active interference canceller for anti-jamming

Enable and operate GNSS as follows:

1. Plugin an active GNSS antenna to the external SMA-Antenna port.
2. Login to the router terminal via ssh
3. Type to console:

```
uci set gpsd.core.enabled=1
uci commit gpsd
```



## MC-MNR 5G Router

```
/etc/init.d/gpsd enable  
/etc/init.d/gpsd start
```

4. Test GPS typing "gpsmon".

MC|  
TECHNOLOGIES  
We connect the industry  
CONFIDENTIAL

MC|  
TECHNOLOGIES  
We connect the industry  
CONFIDENTIAL

## 10 WATCHDOG SYSTEM IN MNR

The MNR is equipped with two hardware watchdogs: `adv-i2c-wdt` and `stm32-wdt`. The latter is integrated into the MC-Extension module. While `adv-i2c-wdt` safeguards only the Single Board Computer (SBC) within the MNR, `stm32-wdt` also manages power control for both modems and the entire hardware system.

These watchdogs ensure the MNR remains operational and protect the system in the following cases:

- User-space inaccessibility
- Kernel crashes

### 10.1 USER-SPACE INACCESSIBILITY

A system must remain accessible at all times. However, corrupted user-space applications may render the system unresponsive. In such scenarios, a reboot or power cycle is necessary. To simulate a rogue application, we can use a fork bomb, a well-known denial-of-service attack that depletes system resources, leading to resource starvation and a crash.

```
foo () { foo | foo & } && foo
```

This recursive function overloads system resources, making user space inaccessible and subsequently triggering the watchdog reset.

### 10.2 KERNEL CRASH

Kernel modules may malfunction, causing kernel panics. The hardware watchdog ensures a clean restart in such cases. To simulate a kernel panic, we can use the following command:

```
echo c > /proc/sysrq-trigger
```

### 10.3 ADV-I2C-WDT

Since the `adv-i2c-wdt` is integrated into the SBC, it is directly managed by the Linux operating system and can be fully configured from user space.

#### 10.3.1 USAGE VIA UBUS

OpenWrt includes a watchdog daemon (`watchdogd`), a system tool that automatically starts the Power Management IC (PMIC) watchdog and periodically writes "1" to `/dev/watchdog` to keep it active. `watchdogd` can be controlled via the UBUS API.

- View watchdog parameters and status:

```
ubus call system watchdog
{
  "status": "running",
  "timeout": 30,
  "frequency": 5,
  "magicclose": false
}
```

- Change heartbeat (timeout), minimum value: 10 seconds:

```
ubus call system watchdog '{"timeout":10}'
```

- Stop watchdog pings (this will lead to a reboot after the timeout period):

```
ubus call system watchdog '{"stop":true}'
```

### 10.3.2 USAGE WITHOUT WATCHDOG DAEMON

1. Deactivate watchdogd.
2. Add the magic close flag to stop the watchdog device:

```
ubus call system watchdog '{"stop":true,"magicclose":true}'
```

3. Start the hardware watchdog manually:

```
echo 1 > /dev/watchdog
```

4. Ensure periodic pinging to prevent automatic reboot (default timeout: 4 seconds):

```
while true; do echo 1 > /dev/watchdog; sleep 5; done
```

5. Stop the hardware watchdog:

```
echo V > /dev/watchdog
```

### 10.4 STM32-WDT

Unlike `adv-i2c-wdt`, `stm32-wdt` is not configurable and cannot be disabled. It operates at the kernel level and will initiate a full hardware power cycle if it does not receive a ping within 5 minutes.

## 11 INITIAL STARTUP OF ROUTER

1. Insert SIM-Cards
2. Plugin Power Supply
3. Establish Network Connection to PC

**Attention: DHCP-Server enabled!**

Coming from factory the DHCP-Server on the MC-MNR is activated. After connecting to your PC an IP-Address "192.168.2.x" is assigned automatically.

**Alternative A:** Plugin Ethernet Cable into RJ45-Port "LAN1" and Connect with your PC.

**Alternative A:** Wifi- Connection

Scan QR-Code on Side of MC-MNR or this one:


**WiFi QR**




mE5%VD2!

Alternatively: Search SSID "MC-MNR-WiFi" with your wifi-client on your PC and enter password "mE5%VD2!"

4. Open Web-Interface  
Type the IP-address "192.168.2.1" of the router in a web browser on the PC.




Enter user "root" and passwd "Tech#5GR".



5. Change Password

Please change the password before establishing an internet connection.



### 6. Setup SIM-Pin and APN

Well done, you are ready to go!

## 12 CONTACT INFORMATION

MC Technologies  
Kabelkamp 2  
30179 Hanover  
Germany  
mc-technologies.com  
support@mc-technologies.com  
Tel: +49-511-676999-0  
Fax: +49-511-676999-150  
© 2025 MC Technologies  
Errors and omissions excepted  
All rights reserved